


# QUICK START GUIDE

Thank you for purchasing an Imperative Light!  
This guide will get you up and running quickly.  
Consult the included Instruction Book for more details


**Step 1:** Insert the included adapter into a wall socket.




**Step 2:** Insert one end of the included USB cable into the adapter, and the other end into the USB socket on your light.



**Step 3:** Flip the power switch to the "on" position.



**Step 4:** The light will start up in Showcase mode. Use one of the included remote controls to change the light settings.




Read the other side of this guide for more information  
▼ about the remote control. ▼

# REMOTE CONTROL GUIDE

Press a number key to select a light art program.

<b>1 - Shimmer</b>	<b>2 - Pulse</b>	<b>3 - Whirlpool</b>
<b>4 - Rays</b>	<b>5 - Actors</b>	<b>6 - Automata</b>
<b>7 - Sound React</b>	<b>8 - Flicker</b>	<b>9 - Game</b>
	<b>0 - Showcase</b>	

Press a number multiple times to load program variants!



The OK key sets hue/brightness to the default and resets the currently running program.